


Plasma Direct Installation Instructions for A35 M26 engine

Thank you for your purchase. Please read this instruction carefully to make a proper and safe installation.


Safety Instructions




1. Installation should be made only on designated vehicles and models.
2. Never modify or dismantle this product.
3. The vehicle should be on a flat surface, with tires blocked to prevent the vehicle from rolling.
4. The engine should be off and completely cooled. Be sure the ignition key is not inserted.
5. The negative terminal from the battery should be disconnected. Note that this may cause the security alarm to activate. Consult the vehicle owner's manual to prevent this from occurring.
6. The engine should be in good operating condition. Any sign of defects should be corrected before installation.
7. Make sure you have adequate ventilation before running the engine.
8. Installation should be performed by a professional mechanic.
9. If the engine performance was previously boosted through modification of the ignition timing or air/fuel ratio, it may require readjustment following installation of the product.
10. If any defects are found in the product, discontinue using it immediately and contact the dealer where you purchased the product or us.

Parts Included


4 x Plasma Direct



4 x Plug boot




1 x Spacer




Installation Procedure


- 1** Remove the engine cover and shift the intake pipe to expose the ignition coils.




- 3** Disconnect the coil connectors and remove the ignition coils from the engine.




- 2** Remove the spacer from the engine. This part will no longer be used. Keep it at hand.



- 4** Attach the plug boots provided to the Plasma Directs.




- 5 Install the Plasma Directs to the engine and connect the coil connectors.



⚠ Caution Never fail to follow this instruction.

Tighten the bolt by hand until no longer possible, then use a tool to secure the fastening. Screwing using a tool from the beginning might place too much force on the bolt-tightening and cause damage to the Plasma Directs.

- 6 Attach the spacer provided to the same place as Step 2.



- 7 Mount back properly all the components you removed or shifted for the installation.

PD4003107R
A35 2/2



OKADA PROJECTS Inc.
2-3-5 Kitamigata, Takatsu-ku, Kawasaki-shi Kanagawa 213-0005 Japan
www.okadaprojects.com info@okadaprojects.com

All rights reserved. Reproduction in any form without written permission from Okada Projects is prohibited.