



Renault Megane 225/230 Boost hard pipe Kit



Tools needed:

- 10mm socket
- 3/8 or 1/4" ratchet
- Hose clamp driver
- T15 Torx
- T25 Torx
- T30 Torx