


Dual Fuel Pump Hardwire Kit FPHWK-10-DP



Get the most out of your DW high flow fuel pump by ensuring it gets the voltage it needs. Old, compromised OE wiring can limit the voltage your fuel pump receives. Our Dual Pump hardwire kit includes everything you need to safely, easily, and reliably wire your pumps directly to your battery, ensuring no matter how hard you push your pumps, your wiring will be up to the task. We especially recommend this kit for use in cars over 10 years old, cars making over 800whp, and cars which were originally not designed for high horsepower.

Relay Diagram



Specifications

Ground Wire	3x 6' 10awg SLX Automotive Wire*
Power Wire	2x 15' 10awg SLX Automotive Wire
Relay Spec	2x 40-amp Bosch Automotive
Fuse Spec	2x 30-amp ATO Bladed Fuse
Socket Spec	2x 4-lead (Color Coded)
Covering Spec	Nylon Expanding Loom

Connections

Relay Socket Wire	Purpose	Connects To
Black (85)	Ground to Relay	Chassis (GND)
Yellow (87)	Power to Pump	"Pump Side" (+) Lead
Blue (86)	Switch to Relay	"Harness Side" (+) Lead
Red (30)	Power from Battery	Battery Terminal (+)

* The dual pump hardwire kit includes a 3rd black 10awg ground wire for the fuel pump ground.

THIS PRODUCT MAY BE USED SOLELY ON VEHICLES USED IN SANCTIONED COMPETITION WHICH MAY NEVER BE USED UPON A PUBLIC ROAD OR HIGHWAY, UNLESS PERMITTED BY SPECIFIC REGULATORY EXEMPTION